## SPECIAL WINTERIZATION INSTRUCTIONS FOR RV/MARINE INSTALLATIONS:

## To winterize your ARWXF129W washer,

- With washer-dryer power OFF, pour 1/2 quart of RV-type antifreeze into washer drum;
- Close door. Advance Cycle Selector to 'B':
- Press **ON/OFF** button, then **WINTERIZE** press START. let the washerdryer run for 1 to 2 minutes;
  - Press **ON/OFF** button to turn power OFF.
  - 5. Unplug washer-dryer from electrical outlet (or disconnect power);
  - **6.** Turn water supply faucets OFF. Disconnect inlet hoses from faucets;
  - Drain remaining water from the hoses. FINISHED.



END

## To use your washer again,

- Reconnect water inlet hoses to corresponding HOT/COLD faucets. Turn faucets ON. NOTE: Check water inlet hoses and pump periodically (see Users Guide);
- 2. Plug washer-dryer into appropriate electrical outlet (see Users Guide) - OR reconnect power supply;
- With washer-dryer power OFF, pour 1/2 TBSP. of powder detergent (or liquid equiv.) into *compartment '2'* inside Dispenser Drawer,
- ERIZE Advance Cycle Selector to position '4';
  - Press ON/OFF button, then press START.
  - Allow machine to run through the complete cycle to clean out any remaining antifreeze. FINISHED.

END

## **Optional Winterization** Instructions

If you're currently pumping antifreeze through your fresh water system, you can follow these steps to winterize your washer-dryer:

- 1. With machine power OFF, advance Cycle Selector to position '3';
- Press ON/OFF button, set water temperature to WARM, then press **START**. Let machine fill until the drum turns (could take up to 1 to 2 minutes);
- Press **ON/OFF** button to turn power OFF;
- Advance Cycle Selector to 'B';
- **Winterization Option** Press ON/OFF button, then press START.

After letting antifreeze drain completely from drum, press the **ON/OFF** button to turn power OFF. FINISHED.

IMPORTANT! DO NOT DISCARD! Keep this page with your owners manual for future reference

ENP ENP